

2019 Audi Maintenance Schedule - All Models

MY 2019 Audi e-tron Maintenance Intervals - USA

Service intervals in miles												
	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
Minor Maintenance (Every 1 year) ¹	X		X		X		X		X		X	
Standard Maintenance (Every 2 years) ²		X		X		X		X		X		X
Additional Maintenance Items	Refer to the Additional Maintenance Items Table below											

- 1) First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.
- 2) First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.

NOTE: The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Check all completed items

Minor Maintenance

- Brake system - Check the thickness of the brake pads
- Connected box battery - Check state of health with Vehicle Diagnostic Tester in Guided Functions
- First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)
- Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play
- Instrument cluster - Check warning and indicator lights
- Service reminder indicator display - Reset display
- Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)
- Tires - Check condition and tire tread wear; Check and record the tread depth
- Tires - Check tire inflation pressure and adjust if necessary
- Tire repair kit - Check and record the completeness and expiration date (if equipped)
- Wiper blades - Check condition and replace if necessary

Standard Maintenance (Includes All Minor Maintenance Items)

- Body/chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open
- Brake system - Check the thickness of the brake pads
- Brake system - Check for damage and leaks, condition of brake lines and the presence of the bleeder caps
- Charging socket - Check for contamination and damage
- Connected box battery - Check state of health with Vehicle Diagnostic Tester in Guided Functions
- Cooling system for electrical components - Check coolant level and add if necessary according to procedure in ElsaPro
- Door hinges (including door stay) - Lubricate
- Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, brake lights, license plate lights, and hazard warning lights
- First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)
- Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play



Standard Maintenance (continued)

- Front axle drive - drain coolant (with small cover removed)
- Headlights - Check adjustment
- High voltage cooling system - Check for damage and leaks
- High voltage safety instruction labels - Check safety instruction labels for legibility
- High voltage system components - Check for damage and leaks; check cables and insulation for damage and proper mounting
- Horn - Check function
- Instrument cluster - Check warning and indicator lights
- Interior lights - Check all interior lights, trunk lights, and glove box compartment illumination
- Motor compartment - Check transmission, final drive, and steering for leaks
- Panoramic sunroof system - Check function and drainage system by fluid check according to Elsa (if equipped)
- Plenum chamber and water drain valves: Check for dirt, and clean if necessary
- NOTE:** Time spent cleaning of item is a separate charge for service time
- Road test - Perform
- Rear axle drive - Remove coolant cartridge and empty (with cover removed)
- Safety belts - Check function
- Service reminder indicator display - Reset display
- Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)
- Sunroof system - Check function (if equipped)
- Tires - Check condition and tire tread wear. Check and record the tread depth
- Tires - Check tire inflation pressure and adjust if necessary
- Tire repair kit - Check and record the completeness and expiration date (if equipped)
- Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are properly mounted
- Warning triangle - Check if present (if equipped)
- Windshield washer and headlight washing system - Add fluid if necessary. Check adjustment and function
- Wiper blades - Check condition and replace if necessary

Additional Maintenance Items	
Work to be completed	Interval
<input type="checkbox"/> Brake fluid - Change	Every 2 years regardless of mileage
<input type="checkbox"/> Dust and Pollen filter - Replace	Every 20,000 miles or 2 years, whichever occurs first
<input type="checkbox"/> Fragrance Cartridges - Change (if equipped)	Every 2 years regardless of mileage